Soundcraft Vi6™
User Guide

Soundcraft

IMPORTANT
Please read this manual carefully before using your mixer for the first time.

This equipment complies with the EMC directive 89/336/EEC Modified by 92/31/EEC 93/68/EEC 91/263/EEC and LVD 73/23/EEC modified by 93/68/EEC

This product is approved to safety standards:

IEC 60065: 2001
EN60065:2002
UL6500 7th Edition: 2003
CAN/CSA-E60065-03

And EMC standards
EN55103-1: 1996 (E2)
EN55103-2: 1996 (E2)

For further details contact:
Harman International Industries Ltd.
Cranborne House, Cranborne Road
Potters Bar, Hertfordshire, EN6 3JN, UK

Tel: +44 (0) 1707 665000
Fax: +44 (0) 1707 660742
e-mail: info@soundcraft.com

© Harman International Industries Ltd. 2006, 2007
All rights reserved
Parts of the design of this product may be protected by worldwide patents.
Part No. ZM0346-01 Issue 2.4
E&OE

Soundcraft is a trading division of Harman International Industries Ltd. Information in this manual is subject to change without notice and does not represent a commitment on the part of the vendor. Soundcraft shall not be liable for any loss or damage whatsoever arising from the use of information or any error contained in this manual.
No part of this manual may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, electrical, mechanical, optical, chemical, including photocopying and recording, for any purpose without the express written permission of Soundcraft.

Harman International Industries Limited
Cranborne House
Cranborne Road
POTTERS BAR
Hertfordshire
EN6 3JN
UK

Tel:+44 (0)1707 665000
Fax: +44 (0)1707 660742
http://www.soundcraft.com

Contents

INTRODUCTION 1 -1
SAFETY NOTICES 1 -1
SAFETY SYMBOL GUIDE 1 -1
IMPORTANT SAFETY WARNINGS 1 -2
WARNINGS 1 -3
WORKING SAFELY WITH SOUND 1 -4
WARRANTY 1 -4
Soundcraft Vi6™ FEATURES AND SPECIFICATIONS 1 -5
Audio Channels 1 -5
I/O Capability 1 -5
Miscellaneous 1 -6
Channel Processing 1 -6
Control Surface 1 -7
CONSOLE OVERVIEW 1 -8
Bays 1 -8
Layers 1 -9
Encoders 1 -10
Master Audio Functions 1 -11
Master Control 1 -12
SYSTEM COMPONENTS 2 -1
SYSTEM HARDWARE OVERVIEW 2 -2
NOTE ON INSTALLATION OF THE COOLING FANS/FILTERS 2 -3
THE CONSOLE REAR CONNECTORS 2 -4
Mains Power Supply Inlet 2 -4
Audio And Data Rearcon 2 -4
LOCAL RACK 2 -6
Local Rack Description 2 -6
How It Works 2 -6
Front Panel 2 -6
Local Rack Rear 2 -7
Card Function Overview 2 -10
STAGE BOX 2 -13
Stage Box Description 2 -13
Card Function Overview 2 -13
Redundant MADI Cable Operation 2 -14
Front Panel 2 -15
CONNECTING THE PARTS OF THE SYSTEM (With Cat 5 Breakout Panel Fitted) 2 -16
CONNECTING THE PARTS OF THE SYSTEM (Without Cat 5 Breakout Panel Fitted) 2 -18
OPERATION OVERVIEW 3 -1
GENERAL RULES 3 -1
CONVENTIONS USED IN THIS MANUAL 3 -1
SCREENS 3 -1
Input Screens 3 -1
Screen Colour Codes 3 -2
VISTONICS II™ KNOBS 3 -3
AUDIO FUNCTION STATES 3 -3
MOMENTARY/LATCHING CONTROL ACTION 3 -3
SOLO/SEL KEYS 3 -4

LABELLING ..... 3 -4
General ..... 3 -4
Channel Labels ..... 3 -5
BUS CONFIGURATION ..... 3 -6
GANG ..... 3 -7
General ..... 3 -7
Creating A Gang ..... 3 -7
Switching-Off Gang Mode ..... 3 -7
Clearing A Gang ..... 3 -7
Gang All Input Channels ..... 3 -7
INPUT 4 -1
SIGNAL FLOW ..... 4 -1
INPUT CHANNEL STRIP ..... 4 -2
INPUT CHANNEL TOUCH FIELDS ..... 4 -3
Change A Parameter Of An Input Channel ..... 4 -3
INPUT ..... 4 -4
INPUT field ..... 4 -4
GAIN field ..... 4 -5
TRIM field ..... 4 -5
LO CUT field ..... 4 -5
HI CUT field ..... 4 -5
FORMAT field ..... 4 -5
PAIRING field ..... 4 -5
PHANTOM field ..... 4 -5
PHASE field ..... 4 -5
IN1 PATCH field ..... 4 -5
IN2 PATCH field ..... 4 -5
CH Label field ..... 4 -5
DLY field ..... 4 -5
STEREO CONFIGURATION ..... 4 -6
Pairing of input channels ..... 4 -6
Pair An input Channel ..... 4 -6
Stereo Busses ..... 4 -7
EQUALISER ..... 4 -8
General ..... 4 -8
Equaliser Band Highlight ..... 4 -9
BAND Field ..... 4 -9
SHELF Switch ..... 4 -9
EQUALISER Field ..... 4 -9
DYNAMICS ..... 4 -10
General ..... 4 -10
GATE Function ..... 4 -10
DE-ESS Function ..... 4 -12
COMPRESSOR Function ..... 4 -13
LIMITER Function ..... 4 -13
MKUP ..... 4 -13
BUS ..... 4 -14
General ..... 4 -14
AUX (Mono) ..... 4 -14
AUX (Stereo) ..... 4 -14
GRP (Mono) ..... 4 -14
GRP (Stereo) ..... 4 -14
Empty ..... 4 -14
PANNING ..... 4 -15
General ..... 4 -15
PAN Function LR Mode ..... 4 -15
PAN Function LCR Mode ..... 4 -16

..... 4 -16
AUDIO FORMAT ..... 4 -17
General ..... 4 -17
Input Channels ..... 4 -17
Mix Busses ..... 4 -17
Masters ..... 4 -17
PAN/BAL ..... 4 -18
INSERT Function ..... 4 -19
Direct Out Function ..... 4 -19
OUTPUTS 5 - 1
SIGNAL FLOW ..... 5 - 1
GENERAL ..... 5 - 2
L,R & C Master Processing ..... 5 - 3
MASTER EQ LINKING (V2.0 Software and above) ..... 5 - 4
Default settings ..... 5 - 4
MASTER BAY OUTPUT STRIPS ..... 5 - 5
Bus Master Processing ..... 5 - 6
INPUT BAY STRIP USING [ALL BUSSES] ..... 5 - 7
MASTER BAY VISTONICS™ ENCODERS & KEYS ..... 5 - 8
VST Key Function ..... 5 - 8
CHANGING OUTPUT BUS PARAMETERS ..... 5 - 9
Changing A Parameter Of A Bus ..... 5 - 9
EQUALISER ..... 5 - 10
DYNAMIC ..... 5 - 11
PAN ..... 5 - 12
LOW CUT Field ..... 5 - 12
PHASE Field ..... 5 - 12
DLY Field ..... 5 - 12
MATRIX 6 -1
SIGNAL FLOW ..... 6 -1
FUNCTION ..... 6 -1
Adjusting A Matrix Send Level ..... 6 -3
MATRIX CONFIGURATION ..... 6 -3
SOURCE field ..... 6 -3
MTX Point Field ..... 6 -4
ENCODERS 7 -1
GENERAL INTRODUCTION ..... 7 -1
CHANNEL ENCODERS ..... 7 -2
CHANNEL VST ENCODER 1& 2 ..... 7 -3
VST Encoder Priority ..... 7 -3
Changing Encoder Function ..... 7 -4
MASTER BAY PANEL ENCODERS ..... 7 -5
MASTER BAY VST ENCODERS ..... 7 -5
Master Vistonics Switch Function Panel ..... 7 -6
LAYERING (FADER PAGES) 8 -1
GENERAL ..... 8 -1
INPUTS ..... 8 -1
Temporary Layer ..... 8 -2
OUTPUTS ..... 8 -3
Master Fader section ..... 8 -3
ALL Busses ..... 8 -4
VST Master Area ..... 8 -5
VCA & MUTE GROUPS 9 -1
VCA/MUTE GROUP INDICATION ..... 9 -1

MUTE GROUP MASTER SWITCHES ..... 9 -2
VCA CONTROL GROUP BEHAVIOUR ..... 9 -2
AUDIO BEHAVIOUR ..... 9 -2
ASSIGNING VCAs ..... 9 -3
ASSIGNING MUTE GROUPS ..... 9 -3
ASSIGNING VCAS AND MUTE GROUPS TO OUTPUT CHANNELS ..... 9 -3
VCA GROUPS WHEN AUX SENDS ARE CONTROLLED BY CHANNEL FADERS ..... 9 -3
Procedure ..... 9 -4
PATCH SYSTEM 10 -1
SIGNAL FLOW ..... 10 -1
OVERVIEW ..... 10 -2
GENERAL RULES ..... 10 -2
INPUT ..... 10 -3
Patch A Source To An Input Channel ..... 10 -4
Using A Spare Mic For Several Inputs ..... 10 -4
OUTPUT ..... 10 -5
Patch a BUS to an OUTPUT ..... 10 -5
INSERT ..... 10 -6
Patching An Insert Point To An Input Channel ..... 10 -6
Patching Insert Send Or Return Signals To The Connectors Or MADI Channels ..... 10 -7
Stereo Inserts ..... 10 -7
DIRECT OUT ..... 10 -8
KEY SIGNAL ..... 10 -9
MATRIX ..... 10 -10
TIE LINES ..... 10 -11
MONITORING 11 -1
SIGNAL FLOW ..... 11 -1
FUNCTION ..... 11 -1
DESK VIEW ..... 11 -2
SOLO TRIM ..... 11 -2
SOLO BLEND ..... 11 -2
PHONES Volume ..... 11 -2
SETUP ..... 11 -2
Level Meter ..... 11 -3
PFL/AFL Indication ..... 11 -3
ON ..... 11 -3
Monitor Volume ..... 11 -3
Monitor B ..... 11 -3
MONITOR SETUP PAGE ..... 11 -4
SOLO Section ..... 11 -4
MNTR A Section ..... 11 -5
MNTR B and HP Sections ..... 11 -6
DLY Field ..... 11 -7
MONITOR SETUP SUB-PAGE ..... 11 -8
Output Solo Selection ..... 11 -10
SOLO SYSTEM ..... 11 -11
Solo Operation Logic ..... 11 -12
Input Priority Mode ..... 11 -13
Autocancel Behaviour ..... 11 -14
Follow Output Solo Mode ..... 11 -15
TALKBACK & OSCILLATOR 12 -1
DESK VIEW ..... 12 -1
Setup Key ..... 12 -1

TB Mic XLR ..... 12 -1
TB /Osc Level control ..... 12 -1
Routing the TB signal ..... 12 -1
SETUP ..... 12 -2
OSC Section ..... 12 -2
TB Send Section ..... 12 -5
TB Return Section ..... 12 -6
METERING 13 -1
Input Channel Meter ..... 13 -1
Bus Master Meters ..... 13 -2
Master Output Meters ..... 13 -2
Monitor Meters ..... 13 -2
Scale ..... 13 -2
Meters On The Master Section Screen ..... 13 -3
Touch Selection ..... 13 -3
Peak Hold ..... 13 -4
Ballistics ..... 13 -4
MAIN MENU 14 -1
MAIN ..... 14 -1
SECURITY Field ..... 14 -1
BRIGHTNESS Control ..... 14 -1
SHOW ..... 14 -2
GPIO ..... 14 -3
SYNC ..... 14 -4
TIE LINES ..... 14 -5
FX ..... 14 -6
MIDI ..... 14 -7
LOG ..... 14 -8
SETTINGS ..... 14 -9
POINT ..... 14 -9
DEACTIVATE FADER TOUCH ..... 14 -9
SYSTEM MONITORING ..... 14 -10
Overview ..... 14 -10
DESK ..... 14 -11
LOCAL IO ..... 14 -12
STAGE BOX ..... 14 -13
HiQNET ..... 14 -14
SNAPSHOTS AND CUES 15 -1
FRONT PANEL DISPLAY AND CONTROLS ..... 15 -1
SETUP ..... 15 -2
DATA Socket ..... 15 -2
STORE ..... 15 -2
UNDO ..... 15 -2
PREV MODE ..... 15 -2
LAST ..... 15 -2
NEXT ..... 15 -2
The Arrow Keys and RECALL ..... 15 -2
SETUP ..... 15 -3
Snapshop Pool ..... 15 -3
Cue List ..... 15 -3
MANAGING SHOWS ..... 15 -4
Hard Drive ..... 15 -4
Memory Stick ..... 15 -5
Exporting A Show To A Memory Stick. ..... 15 -5
Importing A Show From A Memory Stick. ..... 15 -5

RECORDED DATA ..... 15 -6
Settings Recorded Within A Show Snapshot's Show Settings ..... 15 -6
Settings Recorded Within Audio Settings ..... 15 -7
Settings Not Recorded ..... 15 -7
GPIO 16 -1
CONFIGURATION ..... 16 -1
Screen Touch-Pads ..... 16 -1
GPI VST Keys & Encoders ..... 16 -2
GPO VST Keys & Encoders ..... 16 -2
HARDWARE ..... 16 -4
Schematic Diagram ..... 16 -4
Pin Lists ..... 16 -5
SOUNDCRAFT FaderGlow ™ 17 -1
GENERAL ..... 17 -1
Colour Code ..... 17 -1
COPY, PASTE & LIBRARIES 18 - 1
INTRODUCTION ..... 18 - 1
CONSOLE CONTROL KEYS ..... 18 - 1
COPY & PASTE PRINCIPLES ..... 18 - 2
DATA SELECTION & INDICATORS ..... 18 - 2
PARAMETERS NOT INCLUDED IN CHANNEL & BUS COPY MODES ..... 18 - 3
COPYING CHANNEL OR BUS PARAMETERS ..... 18 - 3
COPYING A BUS MASTER INCLUDING ALL CHANNEL SEND LEVELS ..... 18 - 3
CHANNEL COPY: ITEMS NOT INCLUDED IN COPY WITH SEL BUTTON ..... 18 - 4
BUS OUTPUT COPY: ITEMS NOT INCLUDED IN COPY WITH SEL BUTTON ..... 18 - 4
EXAMPLE: COPYING A WHOLE CHANNEL, INCLUDING THE 'IN1 PATCH' PARAMETER ..... 18 - 4
COPYING FX PARAMETERS ..... 18 - 5
LIBRARIES ..... 18 - 7
NAVIGATING AND MANAGING LIBRARIES ..... 18 - 9
COPY TO LIBRARY ..... 18 - 11
PASTE FROM LIBRARY ..... 18 - 12
EXPORTING AND IMPORTING LIBRARIES ..... 18 - 13
SOUNDCRAFT Vi6™ FEATURES AND SPECIFICATIONS 19 -1
AUDIO CHANNELS ..... 19 -1
Max number of simultaneous mixing channels ..... 19 -1
Insert points ..... 19 -1
Direct Outputs ..... 19 -1
Busses ..... 19 -1
I/O CAPABILITY ..... 19 -1
Local Rack Inputs ..... 19 -1
Local Rack Outputs ..... 19 -1
Stagebox Inputs ..... 19 -1
Stagebox Outputs ..... 19 -1
MISCELLANEOUS ..... 19 -2
Connection from local rack to stagebox ..... 19 -2
Max distance, local rack to stagebox: ..... 19 -2
GPIO facility ..... 19 -2
MIDI ..... 19 -2
CHANNEL PROCESSING ..... 19 -2
Inputs ..... 19 -2
Ouputs ..... 19 -2
CONTROL SURFACE ..... 19 -3
Inputs ..... 19 -3
Outputs ..... 19 -3

Misc ..... 19 -3
Vi6 TYPICAL SPECIFICATIONS ..... 19 -4
BLOCK DIAGRAM 20 -1
Vi Processor™ Card 21 - 1
General ..... 21 - 1
LEXICON® Effects ..... 21 - 1
BSS® Graphic Equalisers ..... 21 - 1
LEXICON® Effects Format ..... 21 - 1
FX Overview Page ..... 21 - 2
Snapshot integration ..... 21 - 2
TAP ..... 21 - 3
ASSIGNING F1-6 KEYS TO FX TAP TEMPO (V2.0 Software and above) ..... 21 - 3
Changing the assignment of F-keys to TAP function ..... 21 - 4
ASSIGNING FX PROCESSORS ..... 21 - 4
Channel Insert ..... 21 - 4
Master Insert ..... 21 - 7
Return in Channel section ..... 21 - 9
FX TYPE ..... 21 - 11
FX DESCRIPTIONS ..... 21 - 13
REVERBS ..... 21 - 13
DELAYS ..... 21 - 15
MISC EFFECTS ..... 21 - 17
BSS® GRAPHIC EQUALISERS ..... 21 - 21